

EEG Motor Movement/Imagery Dataset

Published: Sept. 9, 2009. Version: 1.0.0

EEG Motor Movement/Imagery Dataset *(Sept. 9, 2009, midnight)*

A set of 64-channel EEGs from subjects who performed a series of motor/imagery tasks has been contributed to PhysioNet by the developers of the [BCI2000](#) instrumentation system for brain-computer interface research.

When using this resource, please cite the original publication:

[Schalk, G., McFarland, D.J., Hinterberger, T., Birbaumer, N., Wolpaw, J.R. BCI2000: A General-Purpose Brain-Computer Interface \(BCI\) System. IEEE Transactions on Biomedical Engineering 51\(6\):1034-1043, 2004.](#)

Please include the standard citation for PhysioNet: [\(show more options\)](#)

Goldberger, A., Amaral, L., Glass, L., Hausdorff, J., Ivanov, P. C., Mark, R., ... & Stanley, H. E. (2000). PhysioBank, PhysioToolkit, and PhysioNet: Components of a new research resource for complex physiologic signals. *Circulation* [Online]. 101 (23), pp. e215–e220.

Abstract

This data set consists of over 1500 one- and two-minute EEG recordings, obtained from 109 volunteers, as described below.

Experimental Protocol

Subjects performed different motor/imagery tasks while 64-channel EEG were recorded using the BCI2000 system (<http://www.bci2000.org>). Each subject performed 14 experimental runs: two one-minute baseline runs (one with eyes open, one with eyes closed), and three two-minute runs of each of the four following tasks:

1. A target appears on either the left or the right side of the screen. The subject opens and closes the corresponding fist until the target disappears. Then the subject relaxes.
2. A target appears on either the left or the right side of the screen. The subject imagines opening and closing the corresponding fist until the target disappears. Then the subject relaxes.
3. A target appears on either the top or the bottom of the screen. The subject opens and closes either both fists (if the target is on top) or both feet (if the target is on the bottom) until the target disappears. Then the subject relaxes.
4. A target appears on either the top or the bottom of the screen. The subject imagines opening and closing either both fists (if the target is on top) or both feet (if the target is on the bottom) until the target disappears. Then the subject relaxes.

In summary, the experimental runs were:

1. Baseline, eyes open
2. Baseline, eyes closed
3. Task 1 (open and close left or right fist)
4. Task 2 (imagine opening and closing left or right fist)
5. Task 3 (open and close both fists or both feet)
6. Task 4 (imagine opening and closing both fists or both feet)
7. Task 1
8. Task 2
9. Task 3
10. Task 4
11. Task 1
12. Task 2
13. Task 3
14. Task 4

The data are provided here in EDF+ format (containing 64 EEG signals, each sampled at 160 samples per second, and an annotation

channel). For use with PhysioToolkit software, [rdedfann](#) generated a separate PhysioBank-compatible annotation file (with the suffix .event) for each recording. The .event files and the annotation channels in the corresponding .edf files contain identical data.

Each annotation includes one of three codes (T0, T1, or T2):

- **T0** corresponds to rest
- **T1** corresponds to onset of motion (real or imagined) of
 - the left fist (in runs 3, 4, 7, 8, 11, and 12)
 - both fists (in runs 5, 6, 9, 10, 13, and 14)
- **T2** corresponds to onset of motion (real or imagined) of
 - the right fist (in runs 3, 4, 7, 8, 11, and 12)
 - both feet (in runs 5, 6, 9, 10, 13, and 14)

In the BCI2000-format versions of these files, which may be available from the contributors of this data set, these annotations are encoded as values of 0, 1, or 2 in the TargetCode state variable.






Montage

The EEGs were recorded from 64 electrodes as per the international 10-10 system (excluding electrodes Nz, F9, F10, FT9, FT10, A1, A2, TP9, TP10, P9, and P10), as shown in this [PDF figure](#). The numbers below each electrode name indicate the order in which they appear in the records; note that signals in the records are numbered from 0 to 63, while the numbers in the figure range from 1 to 64.

Acknowledgments

This data set was created and contributed to PhysioBank by Gerwin Schalk (schalk at wadsworth dot org) and his colleagues at the BCI R&D Program, Wadsworth Center, New York State Department of Health, Albany, NY. W.A. Sarnacki collected the data. Aditya Joshi compiled the dataset and prepared the documentation. D.J. McFarland and J.R. Wolpaw were responsible for experimental design and project oversight, respectively. This work was supported by grants from NIH/NIBIB ((EB006356 (GS) and EB00856 (JRW and GS)).

Share



Access

Access Policy:
Anyone can access the files, as long as they conform to the terms of the specified license.

License (for files):
[Open Data Commons Attribution License v1.0](#)

Discovery

DOI (version 1.0.0):
<https://doi.org/10.13026/C28G6P>

Topics:

eeg

neuroelectric

movement

Corresponding Author

You must be logged in to view the contact information.

Files

Total uncompressed size: 3.4 GB.

Access the files












































- [Download the ZIP file](#) (1.9 GB)
- Access the files using the Google Cloud Storage Browser [here](#). Login with a Google account is required.
- Access the data using the Google Cloud command line tools (please refer to the [gsutil](#) documentation for guidance):














































```
gsutil -m -u YOUR_PROJECT_ID cp -r gs://eegmmidb-1.0.0.physionet.org DESTINATION
```

- Download the files using your terminal: `wget -r -N -c -np https://physionet.org/files/eegmmidb/1.0.0/`
- Download the files using AWS command line tools: `aws s3 sync s3://physionet-open/eegmmidb/1.0.0/ DESTINATION`

[Visualize waveforms](#)

Folder Navigation: <base>		
Name	Size	Modified
 S001		
 S002		
 S003		
 S004		
 S005		
 S006		
 S007		
 S008		
 S009		
 S010		
 S011		
 S012		
 S013		
 S014		
 S015		
 S016		
 S017		
 S018		
 S019		
 S020		
 S021		
 S022		
 S023		
 S024		
 S025		
 S026		
 S027		
 S028		
 S029		
 S030		

Name	Size	Modified
 S031		
 S032		
 S033		
 S034		
 S035		
 S036		
 S037		
 S038		
 S039		
 S040		
 S041		
 S042		
 S043		
 S044		
 S045		
 S046		
 S047		
 S048		
 S049		
 S050		
 S051		
 S052		
 S053		
 S054		
 S055		
 S056		
 S057		
 S058		
 S059		
 S060		
 S061		
 S062		
 S063		
 S064		
 S065		
 S066		
 S067		
 S068		
 S069		
 S070		
 S071		
 S072		
 S073		

Name		Size	Modified
 S074			
 S075			
 S076			
 S077			
 S078			
 S079			
 S080			
 S081			
 S082			
 S083			
 S084			
 S085			
 S086			
 S087			
 S088			
 S089			
 S090			
 S091			
 S092			
 S093			
 S094			
 S095			
 S096			
 S097			
 S098			
 S099			
 S100			
 S101			
 S102			
 S103			
 S104			
 S105			
 S106			
 S107			
 S108			
 S109			
 64_channel_sharbrough-old.png		56.1 KB	2009-08-28
 64_channel_sharbrough.pdf		16.9 KB	2009-08-28
 64_channel_sharbrough.png		61.8 KB	2015-08-19
 ANNOTATORS		24 B	2009-08-28
 RECORDS		25.3 KB	2016-04-19
 SHA256SUMS.txt		253.8 KB	2019-02-20
 wfdbcal		1.6 KB	2009-08-06

PhysioNet is a repository of freely-available medical research data, managed by the MIT Laboratory for Computational Physiology.

Supported by the National Institute of Biomedical Imaging and Bioengineering (NIBIB) under NIH grant number R01EB030362.

For more accessibility options, see the [MIT Accessibility Page](#).

[Back to top](#)